



DPH-20U VoIP USB Phone

Quick User Guide

Version 1.0

TABLE OF CONTENTS

1. INTRODUCTION	3
2. PACKAGE CONTENTS	3
3. REQUIREMENTS.....	4
4. DPH-20U INSTALLATION	4
5. ENABLING DPH-20U	10
6. DPH-20U KEYPAD BUTTON.....	11
7. DPH-20U STATES	12
7.1 DPH-20U LCD DISPLAY.....	12
7.2 DPH-20U LEDs	13
7.3 TESTING DPH-20U.....	13
8. UTILITY CONFIGURATION	16
8.1 OVERVIEW.....	16
8.2 SYSTEM	16
8.3 MAPPING MODE.....	17
8.4 SKYPE MODE	17
8.5 EXIT.....	17
9. RECODE	18
10. DISABLING DPH-20U	19
11. UNINSTALL.....	19

1. Introduction

This is a sleek powerful tool and easy to carry USB phone. It has USB port to connect into PC, and it allows you communicate with others through internet. It includes other features to enhance internet voice chat futures, because it has same ability as USB phone such as portable and easy to use, and you can use it for PC to PC or PC to Phone; along with crystal clear voice communication with minimize noise. It has phone's look but it is best to use for family, office or SOHO

2. Package Contents

The DPH-20U package includes the following (note that your particular hardware and cables may look slightly different than shown below).



3. Requirements

In order to install the DPH-20U VoIP USB Phone you will need the following:

1. DPH-20U VoIP USB Phone
2. PC with the following minimum specifications:
 - Pentium 400MHz or equivalent
 - Windows 2000 or XP
 - Available USB port (1.0, 1.1 or 2.0)
 - Skype™ version 1.1.079 or higher (www.skype.com) must be installed
 - 128MB RAM
 - 10MB available hard disk space
 - CD-ROM drive to install DPH-10U software from the supplied CD-ROM

4. DPH-20U Installation

The following instructions will guide you through the process of installing the DPH-20U VoIP USB Phone.

The installation procedure is to:


- Install Skype™ (step 1 below)
- Plug in the DPH-20U WHEN INSTRUCTED TO DO SO (step 2 below)
- Start the DPH-20U software installation (step 3 below)
- Following the installation is OK (step 3 below)
- Use your DPH-20U to make Skype™ calls

The detailed instructions follow:


STEP 1: If Skype™ is not already installed on your computer, visit <http://www.skype.com> and follow the instructions there to install Skype™. Verify that Skype™ is working before installing the DPH-20U.

STEP 2: Connect the DPH-20U USB port as shown below.


You will see the following popup. Press Yes to proceed or No to cancel.



STEP 3: Insert the supplied CD-ROM into your PC CD-ROM drive. The installation should start automatically. Please press “Software(Utility)”.




STEP 4: You will see the following popup. Press Next to proceed or cancel to stop the install processes.




STEP 5: You press the Install and stare to install the DPH-20U Utility.




STEP 6: You will see the following progress bar below indicating that the installation is proceeding.




STEP 7: The program installing audio driver. Press Next.




STEP 8: You will see the driver install path. Press Next



STEP 9: You will see the following progress bar below indicating that the installation is proceeding




STEP 9: You will see the following progress bar below indicating that the installation is proceeding




STEP 10: You will see the following popup. Press Finish to close the installation



STEP 11: You will see the following popup. Press Finish to close the program and restart computer



STEP 12: When you will see the following screen, select the option, “*allow this program to use Skype*” and press the **OK** button.




STEP 13: When the installation completes you should see the following message appear near your system tray and a new telephone icon (circled in red below) in your system tray as shown below.

The USB Phone icon indicates that the DPH-20U software is installed and running and that you can start making calls with DPH-20U




You will see a new program group named “USB Phone”, accessed from the Start button -> All Programs as shown below.




You final configuration should resemble the following.

DPH-20U connect PC




DPH-20U connect NB




5. Enabling DPH-20U

In order to use DPH-20U and its features, (1) the DPH-20U VoIP USB Phone must be plugged into the PC, (2) the DPH-20U utility must be running (see green telephone in the Windows System Tray).

If the DPH-20U utility is not running (i.e. no blue telephone in the system tray), make sure the DPH-20U VoIP USB Phone is connected to the PC and start the DPH-20U as shown below (Start -> Programs -> USB Phone -> USB Phone):



You may see the following screen, select the option, “allow this program to use Skype” and press the **OK** button.



You should now see the DPH-20U in the Windows System Tray as shown below.



You are now ready to use the DPH-20U VoIP USB Phone.

6. DPH-20U Keypad Button

Icon	Define	Description
	Switching AP	for switching Skype mode or Mapping mode. Hold 5 seconds switching back to Logo.
	Switching tabs (Skype mode)	Skype mode: Switching tab. Hold for 5 seconds to turn on and off Skype Focus on AP.
	User define key (Mapping mode)	Mapping mode: User define key(1).
	UP (Skype mode)	Skype mode: Skype page UP.
	User define Key (Mapping mode)	Mapping mode: User define key(2).
	Down (Skype mode)	Skype mode: Skype page DOWN.
	User define Key (Mapping mode)	Mapping mode: User define key(3).
	Delete Black Space (Skype mode)	Skype mode: Clear LCD's dialed number.
	User define key (Mapping mode)	Mapping mode: User define key(4).
	Phone Call/Answer (Skype mode)	Skype mode: Skype answer calls, Hold still for calling Skype.
	User define Key #5 (Mapping mode)	Mapping mode: User define key(5).
	Cancel Calling (Skype mode)	Skype mode: Skype cancel calling, hold still for minimize Skype.
	User define key #6 (Mapping mode)	Mapping mode: User Define function key(6).
	MUTE	Turn off USB Phone MIC,
+	Speaker Volume Up	Speaker volume up.
-	Speaker Volume Down	Speaker volume down.
	Recording	Skype mode: First time start with recording, press it again to stop recording and saving the file.
		Mapping mode: First time start with recording, press it again for stop recording and saving the file.
*		Skype mode: " * "KEY.
		Mapping mode: press once for " * ", hold still for " . ".
#		Skype mode: " # ".
		Mapping mode: " # ".
0		Skype mode: Press once for 0, hold still for +.
		Mapping mode: "0".
1~9		"1~9"Number key.

7. DPH-20U States

Icon	Define	Description
	Skype Mode (ON-Line)	This Mode is for Skype, All the Function keys are default.
	Detecting (OFF-Line)	This mode shows the system can not find USB Phone or utility not enable.
	Mapping Mode	This mode is for VoIP, User is able to set 6 function keys .
	Record	This mode shows the system is recording.

7.1 DPH-20U LCD Display

When the USB Phone is Plug in and loading.



You can press  button to change Mapping Mode and Skype Mode.

Mapping Mode



Skype Mode



In order to show contact list on the display. You can press  button to show the contact list and status from your Skype. You can press  and  button to select your contact list.

Contact list:

·Online



·Offline



·Away



In order to show Call List on the display. You can press  button twice to show the Call List and status from your Skype. You can press  and  button to select your contact list.

Call List:

·incoming calls

·Outgoing calls

·Missed calls



Contact list

Phone call





7.2 DPH-20U LEDs

Showing	Description
LED light ON	Normal mode
Flash	On the Phone
Changing Color	MIC Mute


7.3 Testing DPH-20U

Skype provides a useful feature to test your connection. It is called Echo123. If you send “callme” in a chat with echo123, the echo123 service will call you and let you leave a message which will be played back to you. This will help you verify that the DPH-20U VoIP USB Phone, D-Link driver and the telephone are all connected and installed properly.


Add Echo123 to your Skype contact list from the Skype Tools menu -> Add to Contact List entry as shown below:



When Echo123 is added, click on the chat button as shown below.



You will see the following chat screen and you should enter "callme" and press the Enter key on your keyboard.




Within 10-20 seconds, you should see the following screen, and the DPH-20U VoIP USB Phone should ring. Pick up the handset and follow the instructions. The Echo Test Service will ask you to leave a message which will be played back immediately. This will help you verify that the DPH-20U VoIP USB Phone, DPH-20U Utility and DPH-20U Device are all connected and installed properly.



When the test concludes you can press OK on the following screen.



and then press Finish on the following screen.



8. Utility Configuration

Please right click on the DPH-20U in the system tray and select “Open” as shown below.




8.1 Overview

You can see the software version and firmware version in this page



8.2 System

You can select “Mapping mode” or “Skype Mode” to support your softphone.



8.3 Mapping Mode


If You select “Mapping Mode”. You can define 6 keys to control softphone



After define key. You can save the key value in your computer. The default path C:\Program Files\USB Phone\USBPhone.ini. This files name can be change.

8.4 Skype Mode

If You select “Skype Mode”. You can use default value for the keypad



8.5 Exit

You can press “Exit” to minimize Utility

9. Recode

Please press  button and start to recording



The system will show the icon.





If you need stop recording, press  button.

The system will popup the Windows.


Give a name to Files name. Press save to keep the file in your computer

The record film path is “ My Document/ ”



10. Disabling DPH-20U


In order to disable DPH-20U, right click on the DPH-20U in the system tray and select Close as shown below.




You can now disconnect the DPH-20U from the PC.

11. Uninstall


In order to uninstall the DPH-20U, click on the uninstall utility in the DPH-20U program group accessed from the Start button -> Programs -> USB Phone -> Uninstall USB Phone.



Press Yes to uninstall DPH-20U Utility



You will see the uninstall indicator as follows.



When the uninstall indicator disappears, the un-installation is complete.