

Connecting your SIP/Alarms/Fax


01

Connect your Analogue SIP phone, Fax or Alarm to the grey FXS (SIP) port on the back of your router



02


Launch an Internet browser (Google Chrome, Firefox, Internet Explorer, Safari, etc.) on your connected device. In the URL web address field, type **10.0.0.2** and press enter.



03

Navigate to the following Basic Setup page by clicking on:

1. **Applications** in the menu on the left of the screen
2. Click on **VoIP**
3. Click on **Basic Setup**




04

Fill in the following details as supplied by your Internet Service Provider (ISP):

1. **Register Server**
2. **Outbound Server**
3. Scroll down and select **Enable** under Connection 1
4. Enter your **User Name** (*YourSIPnumber@RegisteredServer*)
5. Enter your **Password**
6. Click **Apply**
7. Select **Instance Id**


Basic Setup



05

Navigate to the following page to verify that your SIP account is successfully connected:

1. Click on **Status** in the menu on the left of the screen
 2. Click on **VoIP**
 3. Select **Voice Status**
 4. The **Voice Register Status** should be "UP"
- If the status says "Registering", please double check that you have entered your details exactly as supplied by your ISP.



Voice Status

Line	Voice Register Status
Line1	UP

Numbered callout 4 points to the 'UP' status.